



LOWE & FLETCHER

LOCKING SYSTEMS FOR INDUSTRY

3780

BATTERY REPLACEMENT

- To check if Batteries require replacement press LOGO button twice.
- Batteries require changing if RED light flashes.



- Enter USER code or Override Key to gain access to locker.
- Remove 2 fixing screws.
- Rotate lock .
- Replace Batteries.
- Re-fit fixing screws.



A Lowe & Fletcher Group Company