Type K-W

re-programmable combination lock

USER INSTRUCTIONS



For further information please contact your probe distributor



SETTING NEW CODES

STEP 1

Your Combination Lock is set at the factory to open at "-0-0-0-0" To set a new code, you need to turn the dials to 0-0-0-0 or the current code if it has already been changed




press and hold the code setting button




Turn the dials to the desired combination and release the button.

STEP 4

Scramble the dials to lock the door.










RESETTING LOST CODES

STEP 1

Insert the master key and turn it 90 degrees to the right.



Turn dials downwards

STEP2

The lock is now open, with the lock and key in this position spin the dials downwards. The dials will stick when they get to the correct number, when all 4 dials have stuck the number on display is the code for the lock. You must push the dials downwards, top to bottom for this to work. You can now reset the code by following the steps outlined above.

For further information please contact your probe distributor

